



C² SUPER HARD™

Step-by-Step Application Instructions – C² Super Hard – Burnished

Before beginning, always read SDS and technical data sheet for complete instructions and safety information. Always prepare a test panel before proceeding.

SURFACE PREP BASED ON THE SURFACE CONDITION AND DESIRED FINISH

- If necessary, grind the surface and finish with 200 resin diamonds. For better sheen finish with 400 resin diamonds.
- Clean the surface well with water and auto scrubber.
- If grinding is not necessary, clean the surface well with auto scrubber only and remove any oil spots.
- Please refer to complete surface preparation for C² Super Hard™ on our technical data sheet.

C² SUPER HARD™ AFTER SURFACE PREP

- Shake C² Super Hard™ well in packaging container.
- Pre wet a microfiber mop with C² Hard™ before application.
- Apply C² Hard™ using a spray applicator and evenly spread with microfiber mop in a swivel motion. Avoid over-application. Continue spray applying sufficient C² Hard™ to maintain a wet edge with the microfiber pad. Best results are achieved when two people are used for application – one to spray the product while the other uniformly distributes the product. Refer to the technical data sheet for how to determine proper application rates.
- Let the surface dry for a minimum of 15-30 minutes.
- Burnish C² Hard™ with a propane driven, high-speed burnisher along with an 800 diamond impregnated pad.

PLEASE NOTE:

- Do not over apply.
- Use ONLY neutral PH cleaner for maintenance. Recommended daily cleaning with C² Clean™ and weekly use of, C² Maintenance™ our lithium based cleaner.
- Please refer to the complete C² Product application instruction available on our website at: www.cretecolors.com